

Adjusting the bed surface to a parallel position

If the upper bed surface is not parallel to the lower part (see photo below), this may have happened because the bed has been moved against the wall.



The photo below shows the adjustable bracket, which is fastened with 2 bolts. Loosen these 2 bolts. Now the lying surface can be adjusted so that the upper lying surface is parallel to the lower part. Then tighten the two bolts again.

